

COMMAND & ERROR CODES

Command Codes

COMMANDS TO ACCESS TO SUB-MENUS

#1	MACHINE TEST	Set number of spiral motors Test and Reset Motors
#2	DATE & TIME	Enters sub-menu for setting the time and date
#3	SETS PRICES	Price setting sub-menu / by selection/ by tray / whole machine: 11/12 etc = Single Selection 91/92 = Shelf 1/2 etc 99 = Entire Machine
#4	SETS DISCOUNTED PRICES	Used to discount food prices
#7	AUDIT DISPLAY	Display of sales for full price selection
#8	AUDIT DISPLAY	Display of sales for discounted price selection
#9	AUDIT DISPLAY	Displays totals cashed not clear-able
#10	AUDIT DISPLAY	Displays totals clear-able Can be cleared through #92

Command Codes

COMMANDS TO SET REFRIGERATION PARAMETERS

#41	SETS CABINET TEMPERATURE	Preset Value is +3°C
#44	SETS DEFROST CYCLE FREQUENCY	N/A on Snack only - ONLY on DUO
#45	SETS FRIDGE CUT OUT DURATION	Sets the cut-out duration for the refrigerstion safety device -ONLY on DUO
#46	SETS TRIGGER TEMP FOR SAFETY	Sets the trigger temperature for the refrigeration safety device - ONLY on DUO
#48	SETS TRAYS WITH SAFETY DEVICE	Setting trays with refrigeration safety device - ONLY on DUO

COMMANDS TO SET MACHINE PARAMETERS

#62	ENABLE DISCOUNT	<pre>0 = No type of discount 1 = Discount for different time slots 2 = Discount for purchases with key/credit card 3 = Discount for time slots and for purchases with key/credit card</pre>
#63	SET THE SINGLE / MULTIVEND	Singlevend 0 / Multivend 1
#64	SETS DISPLAY LANGUAGE	Preset value is 1 for English
#66	INTERNAL TEMPERATURE AND EVAPORATOR TEMPERATURE DISPLAY	The value set determines the info shown on 2nd line of display: 0 0 Displays Clock 1 0 Displays internal Temp 0 1 Displays internal temp + Evap Temp 1 1 Displays clock and internal temp

Command Codes

MBD COIN SYSTEMS

#69	FUNCTIONING MODE OF COIN MECH	SET TO 5 FOR MBD (SET #69 TO VALUE 5 - SWITCH OFF MACHINE - SWITCH ON AND COIN MECH COMMUNICATES WITH MACHINE)
#30	PURCHASE OBLIGATION BEFORE RETURN	Set to 1 which means the customer has to make purchase
#31	SETTING MAX KEY/CASH ACCEPTED	Normally set at 10.00
#32	MINIMUM COIN LEVEL IN TUBES	Used to set change levels
#33	DISABLING SINGLE COINS/NOTES	Used to disable certain coins or notes
#39	FILLING OF THE CHANGE GIVING TUBES	Go into programmimg mode to display Key in 39, Press B, Insert coins int he coin mech, Press B again
#73	ENABLING SECUREVEND	Set to 1 to enable
#93	DISPLAYS THE TEMP STATUS OVER A 24HR PERIOD	Used to check any temperature issues
#94	DISPLAYS THE LAST 10 POWER-OFFS	Used to check if there are heath control issues
#99	VIEW ERROR EVENTS	Used to check error log - refer to main manual for error codes

Error Codes

ERROR CODE MEANING

01	NUMBER SELECTION CODE	Motor blocked / spiral does not rotate
02	NUMBER SELECTION CODE	The spiral does not complete the rotation
05	NUMBER SELECTION CODE	Motor disconnected
09	NUMBER SELECTION CODE	Possible microswitch defect or spiral motor wiring defect
10	(*) 38	Internal temperature feeler faulty
11	(*) 38	Evaporator probe faulty
16	(*) 33-38	Error communication with peripheral
17	(*) 38	Communication break during sale cycle without credit collection
18	(*) 38	Communication break during cycle with credit collection
31	(*) 38	Photocell test error
32-38	(*) 38	Photocell calibration error
39	(*) 38	Photocell safety
51	(*) 38	Interruption of peripheral connection at the beginning of the sale cycle

Error Codes

ERROR CODE MEANING

55	I	Payment system out of service
91	NUMBER SELECTION CODE	Selection not reset

(*) KEY:

33 = PHOTOCELLS 38 = SNACKPOINT