

ERRORS







In the service menu, the error messages can be located in sub-menu 7:

It gives you the option the either read a log of the last 20 error messages, or remove the error log.

Ensure you save the option, before returning out of the sub-menu.











PROBLEM

STEP BY STEP INSTRUCTIONS

E3 - FILL ERROR	BOILER IS FILLING UP TOO SLOWLY	 Check the water pressure. Turn the water supply tap completely open. Check the connection tube for any kinks. Switch the machine off and on again.
E5 - FILL ERROR	BREWER ERROR DURING START-UP	Switch the machine off and on again.Engineer assistance required.
E6 - HIGH TEMPERATURE	TEMPERATURE SENSOR PROBLEM	• Engineer assistance required.
E7 - BREWER MOTOR ERROR	BREWER MOTOR OVERLOAD/STUCK	 Remove the brewer from the machine, clean and reinstall the brewer correctly. Switch the machine off and on again. Use the brush to clean the brewer. Engineer assistance required.
E8 - MIXER 2 ERROR	MIXER 2 OVERLOAD / STUCK	 Remove the mixer from the machine, clean and reinstall the mixer correctly. Switch the machine off and on again.
E10 - VALVE ERROR	VALVE OVERLOAD / STUCK	• Engineer assistance required.
E11 - INGREDIENT MOTOR ERROR	INGREDIENT MOTOR OVERLOAD / STUCK	Clean the canisters.Switch machine off and on again.





PROBLEM

STEP BY STEP INSTRUCTIONS

E13 - MIXER GROUP ERROR	BREWER AND MIXER GROUP OVERLOAD	Clean the mixer impeller.Switch machine off and on again.
E14 - MIXER GROUP ERROR	OUTLET GROUP OF INGREDIENT MOTOR OVERLOAD	Clean the canisters.Switch the machine off and on again.
	VALVE OUTLET GROUP OVERLOAD	• Engineer assistance required.
E17 - MDB ERROR	THERE IS NO COMMUNICATION BETWEEN THE MACHINE AND MDB PAYMENT SYSTEM	 Switch the machine off and on again. Engineer assistance required.
E18 - MIXER GROUP FET ERROR	BREWER OR MIXER MOTOR STILL ACTIVE	• Engineer assistance required.
E19 - OUTPUT FET ERROR	INGREDIENT MOTOR, VALVE OR VENTILATION MOTOR STILL ACTIVE	• Engineer assistance required.
E20 - SOFTWARE ERROR	SOFTWARE ERROR	Switch the machine off and on again.Engineer assistance required.
E21 - BOILER TIMEOUT	BOILER IS NOT HEATING	• Engineer assistance required.
E22 - BREW TIMEOUT	BREWER PROCESS IS TOO LONG	 Switch machine off and on again. Clean or rinse the machine. Engineer assistance required.





PROBLEM

REACH HOME

TIMEOUT

STEP BY STEP INSTRUCTIONS

E23 - INLET VALVE ERROR	INLET VALVE IS LEAKING	Close the water tap.Engineer assistance required.
E24 - BREWER ERROR	BREWER ERROR DURING COFFEE MAKING	Switch the machine off and on again.Engineer assistance required.
E25 - FLOWMETER ERROR	NO WATER PRESSURE. WATER TANK IS EMPTY	 Check water pressure. Open the water supply. Check water hose. Switch machine off and on again.
E26 - LOW TEMPERATURE	TEMPERATURE SENSOR PROBLEM	• Engineer assistance required.
E27 - NTC SHORT CIRCUIT	TEMPERATURE SENSOR PROBLEM	• Engineer assistance required.
E28 - NTC NOT DETECTED	TEMPERATURE SENSOR PROBLEM	• Engineer assistance required.
E29 - BREWER LEAVE HOME TIMEOUT	THE BREWER DID NOT LEAVE THE STARTING POSITION	 Check if brewer motor runs. Check if brewer unit is blocked.
E30 - BREWER REACH BREW TIMEOUT	THE BREWER HAS LEFT THE STARTING POSITION BUT DID NOT REACH THE BREWER POSITION	 Check if brewer motor runs. Check if brewer unit is blocked.
E31 - BREWER LEAVE BREW TIMEOUT	THE BREWER DID NOT LEAVE ITS BREWING POSITION	 Check if brewer motor runs. Check if brewer unit is blocked.
E32 - BREWER	THE BREWER HAS LEFT ITS	Check if brewer motor runs.

· Check if brewer unit is

blocked.

BREWING POSITION BUT

DID NOT REACH ITS

STARTING POSITION





PROBLEM POSSIBLE CAUSE CORRECTION

THE MACHINE IS NOT WORKING

- Broken Fuse
- The machine is switched off.
- Broken Cable

- · Check the Fuses
- Switch on machine
- Check the power cable

THE MACHINE **DOES NOT** RESPOND

The machine is on standby mode.

Switch off stand-by

BAD PRODUCT

TASTE

- The canister is empty.
- The canister is incorrectly positioned.
- The canister chute is blocked.
- The canister auger does not work.
- Wrong Ingredient.
- The ingredient is solidified.
- The mixer is dirty.
- The ingredient has expired.
- The boiler temperature is too low.
- The ingredient is damp.

- Fill the canister.
- · Position the canister correctly.
- · Clean the canister chute.
- · Check the auger and clean if necessary.
- · Use correct ingredient type.
- Replace the ingredient.
- Clean the mixer.
- Replace the ingredient.
- Engineer Assistance required - reset temperature.
- Check ventilation system and replace ingredient.