

# QUICK REFERENCE TO SNACKPOINT RANGE PROGRAMMING MENU

LIST OF PROGRAMME COMMANDS ACCESS TO SUBMENUS		
<b>Command 01</b>	Machine test	Can be used to set number of spiral motors and to test and reset motors
<b>Command 02</b>	Calls submenu for setting the clock and daily timers	Sets date and time
<b>Command 03</b>	Recall of price setting submenu	Sets prices by selection, tray or whole machine 11/12 ETC = SINGLE SELECTION 91 = SHELF 1 92 = SHELF 2 ETC 99 = ENTIRE MACHINE
<b>Command 04</b>	Calls submenu for setting discounted prices	Only used to discount food prices
<b>Command 07</b>	Display of sales for full price selection	Audit display
<b>Command 08</b>	Displays sales for selection discounted price	Audit display
<b>Command 09</b>	Displays totals cashed not clear-able	Audit display
<b>Command 10</b>	Displays totals clear-able	Clear-able audit totals

TO SET REFRIGERATION PARAMETERS		
<b>Command 41</b>	Sets cabinet temperature	Should be set t ...c
<b>Command 44</b>	Sets defrost cycle frequency	N/A on snack only, only applicable on Duo
<b>Command 45</b>	Setting the cut-out duration for the refrigeration safety device	Only applicable on Duo
<b>Command 46</b>	Setting the trigger temperature for the refrigeration safety device	Only applicable on Duo
<b>Command 48</b>	Setting trays with refrigeration safety device	Only applicable on Duo

TO SET MACHINE PARAMETERS		
<b>Command 62</b>	Enable discount	0 = No type of discount 1 = Discount for different time slots 2 = Discount for purchases with key/credit card (only possible in MDB mode) 3 = Discount for time slots and for purchases with key/credit card (only possible in MDB mode)
<b>Command 63</b>	Set the mono/multivend	Default is 0 single vend
<b>Command 64</b>	Sets the message display language	Set to 1 for English
<b>Command 66 - 67</b>	Internal temperature and evaporator temperature display	Displayed value 0 0 Displays clock 1 0 Displays internal temperature* 0 1 Displays internal temperature + Evaporator Temperature 1 1 Displays clock and internal temperature

MBD COIN SYSTEM		
<b>Command 69</b>	Chooses functioning mode of the coin mechanism	Set to 5 for MBD  <i>The 69 command has to be programmed to value 5, then turn off the machine for some seconds. By putting it on again the machine and the coin mechanism will communicate directly.</i>
<b>Command 30</b>	Purchase obligation before return	Set to 1 which means customer has to make purchase
<b>Command 31</b>	Setting max key or cash credit accepted	Normally set at 10.00
<b>Command 32</b>	Minimum coin level in the tubes	Used to set change levels
<b>Command 33</b>	Disabling single coins / bank notes	Used to disable certain coins
<b>Command 39</b>	Filling of the change giving tubes	Go into programming mode to display Key in 39 press B Insert coins in the coin mechanism Press again the push button B
<b>Command 73</b>	Enabling the photoelectric cells - Secure Vend	Set to 1 to enable
<b>Command 93</b>	Displays the temperature status over the last 24 hours	Use to check the temperature issues
<b>Command 94</b>	Displays the last 10 power-offs	Use to check if there are health control issues
<b>Command 99</b>	View error events	Use to check error log refer to full manual for error codes