



FITTING PLINTHS



Equipment Needed:

- 8mm Hex Socket Wrench
- Phillips screwdriver

INSIDE THE MACHINE




PLINTHS

1 - UNPACK PLINTHS




Plinths will have bolts fitted

The bolts must be located closer to the bottom when fitting



The bolts fit into a keyhole connection with the front plinth




2 - FIT SIDE PLINTHS





Remove screws





Slide plinth into back of machine first





Fit plinth to front





Replace screws

6 Re

Repeat steps on other side


3 - FIT FRONT PLINTH





Remove countersink screws x2





Ensure plinth and countersink align





Replace screws x2





Plinths fitted on both sides and front

REFUEL. RECOVER. REPEAT.



CONTACT



Westomatic Vending Services Ltd, Units 7 - 8 Forde Court, Block 4 Forde Road, Newton Abbot, TO12 4BT







+44 (0)1626 323100



sales@westomatic.com



www.westomatic.com