


EASY 6000

**SETTING EXPIRY DATES
& SMART FILL**



Setting / Removing Expiry Dates & Smart Fill



Command 71 – 78: (Drums 1 – 8)

Command 71

Command 72

Command 73


Command 74

Command 75

Command 76

Command 77

Command 78



IMPORTANT – EACH DRUM SHOULD:

CONTAIN **ALL THE SAME** PRODUCT SELECTION
WITH THE SAME SELL BY DATE

FIFO – First In First Out

- This mode is for each drum with a sell by date
- The expiry date starts at the Preceeding Midnight
- The expiry date ends at 'todays' midnight

**eg: If you fill the machine today and enter 1 day it will
end at midnight – 2 days will take it to the next day etc.**


- The drum does not rotate – product sold in order

1

SET SELL BY DATE FOR SPECIFIC DRUM

Enter Programming mode and then

Using Internal Keypad enter Command 75 (DRUM 5)




Service Mode 1



Use Internal Keypad

FOR THIS EXAMPLE
WE WILL USE DRUM 5.



Command 75
(to enter)




Use Internal Keypad


**Repeat
for all
drums**



**Tells us the no. of
compartments in the drum
(to enter)**



**FIFO = First In First Out (1)
Shopper (0)
Input 1 - # (to enter)**




**Input the number of days until
expiry - (sell by date)
(to enter)**

2

TURN OFF EXPIRY DATE FOR SPECIFIC DRUM

Enter Programming mode and then

Using Internal Keypad enter Command 75 (DRUM 5)




Service Mode 1



Use Internal Keypad

FOR THIS EXAMPLE
WE WILL USE DRUM 5.



Command 75
(to enter)



Use Internal Keypad


**Repeat
for all
drums**



**Tells us the no. of
compartments in the drum
(to enter)**



**FIFO = First In First Out (1)
Shopper (0)
Input 0 - # (to enter)**



**Change the number of expiry
days to 0
(to enter)**

3


SMART LOADING OF THE MACHINE

Enter Smart Loading mode 2 and then
Select Drum 5 to fill

FOR THIS EXAMPLE
WE WILL USE DRUM 5.



Smart Loading Mode 2



Fill compartment

Use Drum button to close door and move to next compartment

Repeat to fill the entire drum



Select Drum 5



EASY 6000

