SETTING PRICES & DISCOUNTS



Setting Prices and Discounts



IMPORTANT – Must be done in this order

- SET PRICES FOR EACH DRUM Command 3
- 2 SET DISCOUNT PRICES FOR EACH DRUM Command 4
- SET CLOCK & TIMERS FOR DISCOUNT-Command 2



SET PRICES FOR EACH DRUM


Enter Programming mode and then Using Internal Keypad enter Command 3



Command 3 # (to enter)

Command










SET DISCOUNT PRICES FOR EACH DRUM

Enter Programming mode and then Using Internal Keypad enter Command 4




Programming mode
Command
4

Command 4 # (to enter)











SET CLOCK & TIMERS FOR DISCOUNT

Enter Programming mode and then Using Internal Keypad enter Command 2



Command 2
(to enter)

Programming mode


Command







IMPORTANT – Set Date & Time first





Display clock?
(to enter)
*(to return to menu)




2.Weekly Timers # (to enter)




2.Discount Time Slots # (to enter)



Enable (Press 1) # (to enter)




Select day (using no.2) # (to enter)



Input Start Time # (to enter)



Input End Time # (to enter)



3. Modify this day

Options:

- 1. Copy on the next day copies the settings to the next day
- 2. Copy on all days copies the settings to all days
- 3. Modify this day allows you to change the current settings

(* to save and exit out to the main screen)

EASY 6000



