

## **ERROR CODES - OPERATORS**





## HYDRATION STATION

## **Error Codes - OPERATORS**

## ERROR CODE MEANING

FAULT	CODE ERROR	CORRECTIVE ACTION
#15	WASTE BUCKET FAULTY	<ul> <li>Check the waste bucket is not full - Empty if full of water</li> <li>Ensure waste bucket brass weight is in the waste bucket</li> <li>Ensure the waste bucket is in correct position</li> <li>Ensure that the waste bucket white silicon hose is not trapped or twisted</li> <li>Check the waste bucket for damage</li> </ul>
#17	TRIAC OPEN CIRCUIT	<ul> <li>Check the fault log for a fault prior to this error which may have caused the fault</li> </ul>
#20	WATER FAIL SAFE	<ul> <li>Check the machine for internal leaks</li> <li>Fault code will be rectified by interrupting power</li> </ul>
#40	INTERNAL TIMER	<ul> <li>Check fault log and report error</li> <li>Cycle power to restart machine</li> <li>No further action required unless fault re-occurs multiple times</li> </ul>