

## LOCATING THE ON/OFF SWITCH





## On/Off Switch

IS LOCATED INSIDE THE
MACHINE, NEXT TO THE YELLOW
STICKER ON THE UPPER
SECTION OF THE BACK PANEL

