



ADJUSTING THE FEET




Equipment Needed:

- An adjustable spanner **or**
- A 12 spanner
- A tape measure
- A spirit level

IMPORTANT

 Before you start ensure the foot is down otherwise the nut will not be accessible






LEVELLING THE MACHINE

- Locate the machine on a stable, level surface.
- You will need an adjustable spanner and a spirit level.
- Incorrect levelling can lead to misalignment and inconsistent bottle fill issues.










LEVELLING THE MACHINE

- Using the spanner adjust the foot bolts to raise or lower the machine.
- Ensure you check side to side and front to back to ensure machine is level in both planes.
- NB: Make sure the level is free of the hinge!









REFUEL. RECOVER. REPEAT.



CONTACT



Westomatic Vending Services Ltd, Units 7 - 8 Forde Court, Block 4 Forde Road, Newton Abbot, TO12 4BT



+44 (0)1626 323100



sales@westomatic.com



www.westomatic.com