

# primo

**MINI/MIDI**

**INGREDIENT FILL**

westomatic  
*make it happen*



# FILLING THE MACHINE

These instructions show the steps for Filling the Primo Compact:

- Ensure you have clean hands and fresh ingredients
- Ensure the Canisters have been washed out, cleaned and thoroughly dried prior to filling



1

Unlock and open the machine




2

Open the door, and lift up the top flap to gain access to the canisters



3

Rotate canister chute upwards to prevent any ingredients spilling



4

Carefully lift canister up and pull forward to remove




5

Remove lid and fill canister with ingredient stated on label




6

Replace canister into machine. Replace lid onto canister



7

Rotate canister chute back down  
- repeat filling for all canisters



8

Replace lid and  
close the door



9

Close and lock  
the door of the  
machine - it is  
ready to use





## CONTACT



Westomatic Vending  
Services Ltd,  
Units 7 - 8 Forde Court,  
Block 4 Forde Road,  
Newton Abbot,  
TQ12 4BT

# prigo



+44 (0)1626 323100



[sales@westomatic.com](mailto:sales@westomatic.com)



[www.westomatic.com](http://www.westomatic.com)