

WASTE TO BASE



TECHNICAL INFORMATION - MINI

The Primo Mini is a slimline Instant Machine. The machine has 3 canisters, is capable of 24 different drink choices, and produce a drink every 10 seconds:

- External Dimensions:
 W409xD569xH520mm
- Capacity Instant Canisters:
 1x2.3L and 2x1.2L
- Noise Emission: <70dB
- Weight: 18kg





TECHNICAL INFORMATION - MIDI

The Primo Midi is an Instant
Machine capable of 24 different
drink choices, and with 4 canisters
provides a great variety. The Midi
can produce a drink every 10
seconds:

- External Dimensions: W409xD520xH569mm
- Capacity Instant Canisters: 4x1.2L
- Noise Emission: <70dB
- Weight: 23kg





INSTALL WASTE TO BASE DRAIN

There is the option to have plumbed drainage from the drip tray to waste water drain:

Required Items:

- The Primo Drain Hose WVS
 PN: 1057278 (Midi) (if needed)
- A screw driver
- Combination Pliers

NB: The machine must be situation within close proximity of a waste water drain - and there needs to be height differential to ensure the water flows freely into the drain.





Remove the drip tray from the machine



4

Route the hose to the rear under the machine.



2

Drill a 6mm hole in drip tray connector.



(5)

Place and fix the drain hose in the waste water drain.



3

Connect the drain hose to the drip tray connector.



6

Replace drip tray at the front of the machine.





CONTACT



Westomatic Vending Services Ltd, Units 7 - 8 Forde Court, Block 4 Forde Road, Newton Abbot, TQ12 4BT







+44 (0)1626 323100



sales@westomatic.com



www.westomatic.com