

# primo

**MINI/MIDI**

**WEEKLY CLEANING**

westomatic  
*make it happen*



# CLEANING THE MACHINE

These instructions show the steps for WEEKLY cleaning of the Primo Mini/Midi:

- Cleaning the ingredient mixer parts
- Clean the drip tray and cup tray



1 

Select the menu  
of the machine  
If menu not  
visible - unlock  
door



2

Select clean  
machine




3

Open the door  
and lift the top  
cover



4

Rotate the  
canister chutes  
upwards



5

Remove the  
canisters by  
lifting them up  
and pulling  
forwards



6

Remove the  
hoses from the  
mixing bowls



7

Remove the 90° outlet



10

Push the whipper base to the right - unlocking it



8

Remove hose from the outlet



11

Remove the mixing bowl and repeat for other bowl



9

Repeat for both mixing bowls



12

Remove both dust trays





13

Remove both the impellers



14

Turn the whipper base further right - repeat for both



15

Remove both whipper bases from the machines



16

Using a mild detergent wash all contact parts



17

Important: Dry all parts to prevent any sticking of ingredients



18

Replace both whipper bases - carefully



19

Lock the whipper base in place by rotating it clockwise



20

Replace the whipper impellers - spin them to test



21

Replace the dust trays



22

Replace the mixing bowls



23

Lock the whipper bases into place by rotating further clockwise



24

Replace the hoses and 90° outlets into place



25

Clean the canister area using the brush



26

Replace the canisters - make sure they connect to motor at back



27

Rotate the canisters chutes back into position



28

Close the lid, and the door, and lock the machine



29

Place the container under the outlet



30

Select the rinse function and allow it to rinse - approx 3 mins





31

When the rinse has finished NEXT and remove and empty container



32

Rinse complete



33

Remove the cup tray grill



34

Remove the drip tray and the grill



35

Wash with mild detergent



36

Ensure parts are dried thoroughly





37

Wipe the cup tray and the splashback



38

Rinse the drip tray grill and drip tray into machine



39

Replace the cup tray grill



41

Primo Mini/Midi is now ready to use





## CONTACT



Westomatic Vending  
Services Ltd,  
Units 7 - 8 Forde Court,  
Block 4 Forde Road,  
Newton Abbot,  
TQ12 4BT

# primo



+44 (0)1626 323100



[sales@westomatic.com](mailto:sales@westomatic.com)



[www.westomatic.com](http://www.westomatic.com)