

6 MONTHLY CLEANING



CLEANING THE MACHINE


These instructions show the steps for 6 MONTHLY cleaning of the Primo Maxi:

- Cleaning the ingredient mixer parts
- Clean the drip tray and cup tray
- Clean the canisters & chutes




1

1.03.02 - counters/service-counters/rinse& cleancounters




4

Grease the O-Ring for the mixer bowl.



2

Check:
Rinse is done
daily, Cleaning
Tablet weekly.



5

Remove, clean & dry the dust tray.



3

Remove the mixer bowl & base - check the condition of the seals and the motor turns.



6

Clean and replace the Mixer base and Mixer bowl.






Grease the O-Ring on the door for smooth closing of the machine.




Remove the brewer from machine, then remove back cover.



Slide out funnel.
Remove piston
cover - access to
dirty cover of
upper piston











Remove the screw of the lower piston filter.



Take out the upper filter and ring







to remove the lower piston from chamber





Clean the brewer under hot water - ensure coffee removed from upper piston




Dry the brewer with cloth - grease lower piston shaft



Replace:
Filters / Filter
Ring / Piston
cover / Funnel /
Back of brewer









Finally - grease the door lock.





CONTACT



Westomatic Vending Services Ltd, Units 7 - 8 Forde Court, Block 4 Forde Road, Newton Abbot, TQ12 4BT







+44 (0)1626 323100



sales@westomatic.com



www.westomatic.com