

primo

MINI/MIDI

COPY MACHINE SETTINGS

westomatic
make it happen



COPY MACHINE SETTINGS


1 Using an SD card - you can easily copy/clone the machine settings to other machines



- 2
- Open the rubber cover
 - Insert SD Card - golden contacts towards you



3 Select 08 SOFTWARE



4 Select 02 SAVE DATA



5

SAVE DATA:

Select 01 PERSONAL SETTINGS and press OK to save the personal settings file (.mdu) on the SD Card.

Select 02 RECIPE and press OK to save recipe file (.rcu/mvu) on SD CARD.



6


Remove SD card and place into Recipient machine.

NB must be same model and variant of machine.




7

Select 08 SOFTWARE



8

Select 01 LOAD DATA / SOFTWARE



9

Select 01 PERSONAL SETTINGS

- Select the .mdu file which is written on the card and press SAVE

Select 02 RECIPE

- Select the .rcu file which is written on the card and press SAVE



10

Remove SD Card



*If a pop up screen shows FILE NOT PRESENT check if the machine MODEL & VARIANT settings match.



CONTACT



Westomatic Vending
Services Ltd,
Units 7 - 8 Forde Court,
Block 4 Forde Road,
Newton Abbot,
TQ12 4BT

prigo



+44 (0)1626 323100



sales@westomatic.com



www.westomatic.com