

primo

TOUCH/4

DISPLAY MESSAGES

westomatic
make it happen





PROBLEM	POSSIBLE CAUSE	CORRECTION
OUT OF ORDER BOILER FILLING	<ul style="list-style-type: none"> Boiler is still empty Boiler is not filling up or is filling up too slowly 	No action required
OUT OF ORDER BOILER HEATING	<ul style="list-style-type: none"> The boiler temperature is too low because too much water is used. 	Wait until the boiler temperature has reached the correct level
OUT OF ORDER DRIP TRAY FULL	Drip Tray is full	Empty drip tray
OUT OF ORDER WASTE BIN FULL	Waste Bin is full	Empty waste bin
OUT OF ORDER WASTE BIN IS MISSING	Waste Bin is missing	Replace waste bin
OUT OF ORDER DOOR OPEN	The door is open	Close the door or use the door pin
OUT OF ORDER STAND-BY	The machine is on stand-by	Remove the stand-by mode in the configuration menu.
CLOSE DOOR	The door is not closed correctly	Close the door
RINSE	The rinsing program has not been carried out.	Carry out the rinsing program
SERVICE BOILER	The boiler needs service	Engineer assistance required.
CUP SENSOR LEFT ERROR	There is a problem with the left cup-sensor.	Engineer assistance required.



PROBLEM	POSSIBLE CAUSE	CORRECTION
---------	----------------	------------

CUP SENSOR MIDDLE ERROR	There is a problem with the middle cup-sensor.	Engineer assistance required.
CUP SENSOR RIGHT ERROR	There is a problem with the right cup-sensor.	Engineer assistance required.