



HYDRATION STATION

ADJUSTING DRINK PRICES



USING THE BUTTONS

PRE SOFTWARE UPDATE

- ① Button 1 = UP
- ② Button 2 = DOWN
- ③ Button 3 Quick = BACK
Long = SELECT
- ✗ Button 4 = Not Used



POST SOFTWARE UPDATE

- ① Button 1 = UP
- ② Button 2 = DOWN
- ③ Button 3 = BACK/CANCEL
- ④ Button 4 = ENTER/CONFIRM



1 - PUTTING THE MACHINE ON PAY VEND

1



- Open Door
- In DOOR OPEN mode
- Scroll down to SERVICE MODE
- Using the Buttons -Input code 3211

2



- In Service Mode
- Scroll to MACHINE SETTINGS
- Using the Button - SELECT

3



- Scroll down to PAYMENT SETTINGS
- Using the Buttons - SELECT

4



- Scroll to PAYMENT SYSTEM
- Using the Button - SELECT

5



- In PAYMENT SYSTEM
- If FREEVEND is ✓
- It overrides ALL payment Settings


6



- Scroll to CARD / COIN MECH
- Using the Button - SELECT
- This takes the machine OFF FREEVEND and allows price changes

2 - SETTING THE DRINK PRICES

1



- Return to MACHINE SETTINGS
- Scroll to PRICE SETTINGS
- Using the Button - SELECT

2



- To set all drink prices the same
- Scroll to ALL PRICES
- Using the Button - SELECT

3



- SET ALL TO - makes all drinks the same price
- Using the UP & DOWN buttons to change the amount
- Using the Buttons - SELECT

4



- Back in PRICE SETTINGS
- Scroll to INDIVIDUAL PRICES
- Using the Button - SELECT

5



- In INDIVIDUAL PRICES
- Can set prices for each Drink Option
- Using the Button - Select

6



- Using the UP & DOWN buttons to change the amount
- Using the Buttons - SELECT
- Repeat for all drinks

3 - DISPLAY PRICES ON LCD

1



- Return to PRICE SETTINGS
- Scroll to PRICE DISPLAY
- Ensure LCD is ✓
- Using the Button - SELECT

IMPORTANT:

MAKE SURE YOU KEEP GOING BACK OUT OF THE MENU UNTIL IT 'SAVES THE SETTINGS' OTHERWISE YOUR CHANGES WON'T BE STORED

Water

IS LIFE - DON'T WASTE IT



CONTACT



Westomatic Vending
Services Ltd,
Units 7 - 8 Forde Court,
Block 4 Forde Road,
Newton Abbot,
TQ12 4BT



+44 (0)1626 323100



sales@westomatic.com



www.westomatic.com