



snackpoint media

SETTING PRICES

SETTING PRICES

1 ACCESS THE MENU

Press Button 1 on back of the door.




2 MACHINE PARAMETERS

Enter machine parameters screen.



3 SELECTIONS MANAGEMENT

Enter selections management screen.




4 PRICES

Enter prices screen.



SETTING PRICES

- 5 SELECT AN ITEM**
Highlight a selection item.



- 6 INPUT PRICES**
NB. Do not enter a decimal point.



PRICE 1: Primary price.
PRICE 2 & 3: Different pricing periods.

Can apply to a single selection, a complete shelf or the entire machine.

PRESS SAVE ICON



ENSURE YOU EXIT ALL THE WAY OUT UNTIL IT SAVES!



CONTACT



Units 7-8 Block 4 Forde
Court, Forde Road,
Brunel Industrial
Estate, Newton Abbot,
Devon, TQ12 4BT

snackpoint

westomatic
make it happen



+44 (0)1626 323100



support@westomatic.com



www.westomatic.com