

EVOLVE

FUEL YOUR BODY

6 MONTH CHECK UP!



6 month Check up!

Key areas to look at:

STERILISE

- Water Lines
- All contact & hygiene parts

REPLACE

- UV Filter
- Water Filters
(Microplastics/Sediment)

CLEAN

- Bottle Dispense Area
 - Floor
 - Door
 - Waste bucket
- Using a microfibre cloth & sanitising spray:
- Hover Select Buttons
 - Digital Screen

TEST

- Test all drinks
- Adjust levels if necessary

CLEAN!

Safety Checks:

- **PAT test machine** - Insulation & Earth Bond only
- **Check Mains Lead** - for damage/do not connect to extension lead
- **Check Fuses** - correct value and type
- **Check Looms** - connections are free from damage and fully secured



Tools Required

PAT Tester
Vending Hydrogen peroxide sanitiser
Soft Microfibre cloths
Sanitising Spray
Cleaning Cloths
Bucket of warm sanitising water
Scale / Jug / Cup for testing

Estimated Labour Time - 0.75hrs

PARTS LIST



**Evolve
Hygiene Kit**

PN: 2100039



**Nozzle -
Spout
Dispense
Tube**

PN: 1044002



UV Filter Kit

PN: 2100047



**Tubing -
8mm x 2mm**

PN: 1029012



**Water Filter
Microplastics**

PN: 1024023



**Water Filter
Sediment**

PN: 1024024



**Canister -
Small**

PN: 1012003



**Canister -
Large**

PN: 1012044