



HYDRATION STATION

6 MONTH CHECK UP!





HYDRATION STATION

6 month Check up!

Key areas to look at:

STERILISE

- Water Lines
- All contact & hygiene parts

SANITISE

- Juice Lines

REPLACE

- UV Filter
- Water Filters (Microplastics/Sediment)

CLEAN

- Bottle Dispense Area
 - Floor
 - Door
 - Waste bucket
- Using a microfibre cloth & sanitising spray:
- Hover Select Buttons
 - Digital Screen

CLEAN!

Safety Checks:

- **PAT test machine** - Insulation & Earth Bond only
- **Check Mains Lead** - for damage/do not connect to extension lead
- **Check Fuses** -correct value and type
- **Check Looms** - connections are free from damage and fully secured



Tools Required

- PAT Tester
- Vending Hydrogen peroxide sanitiser
- Soft Microfibre cloths
- Sanitising Spray
- Cleaning Cloths
- Bucket of warm sanitising water

Estimated Labour Time - 0.75hrs

PARTS LIST



**H2O
Hygiene Kit**

PN: 2100003



**Tubing -
Clear PVC -
6mm x 9mm**

PN: 1029037



UV Filter Kit

PN: 2100047



**Tubing -
8mm x 2mm**

PN: 1029012



**Water Filter
Microplastics**

PN: 1024023



**Water Filter
Sediment**

PN: 1024024