

EASY 60000PRO

12 MONTH CHECK UP!



westomatic
make it happen

EASY 60000

12 month Check up!

Key areas to look at:

FRIDGE	Disconnect and Remove - • Clean thoroughly and test probes • Check Fans moving smoothly • Check cut out temperature
HEALTH CONTROL	• Check trigger temperature set to 8 degrees
COMMAND #1	• Check Delivery Doors / Drums are running smoothly • Clean Drums • Check free of any waste / packaging
COIN MECH	• Clean / Test / Refill • Check reject mechanism

REPAIR

Safety Checks:

- **PAT test machine** - Insulation & Earth Bond only
- **Check Mains Lead** - for damage/do not connect to extension lead
- **Check Fuses** -correct value and type
- **Check Looms** - connections are free from damage and fully secured

Tools Required



PAT Tester
Portable Hoover
Cross Head Screwdriver



Estimated Labour Time - 0.75hrs

PARTS LIST



**Temperature
Probe**

PN: 1021324



**Evaporator
Fan**

PN: 1021855



**Drum -
Gear Motor**

PN: 1021293



**Door -
Gear Motor**

PN: 1021525



**Motor -
Condensor
Fan (CO2
fridge)**

PN: 1021895



**Fan
Blade
23mm**

PN: 1021722



**Push Button -
Product
Selection**

PN: 1021260



**10" Tablet /
Touchscreen**

PN: 1021886